


-1G.






FIG. 3





FIG. 4



STEP	STEP FROM	10	SOURCE IP	DESTINATION IP	SERVICE
					PORT
_	U1 (CLIENT) PACKETING	PACKETING	5	M	D1
		ENGINE			•
2	PACKETING	S1	10	S1 (IF NAT IS	D1
	ENGINE	(SERVER)		REQUIRED); W1 (IF S1	•
				SUPPORTS LOOPBACK	
				OR ALIAS)	
က	S1	PACKETING	S1 (IF NAT IS	<u>U1</u>	P1
		ENGINE	REQUIRED); W1 (IF S1		•
			SUPPORTS LOOPBACK		
			OR ALIAS)		
4	PACKETING	101	W1	<u>U1</u>	P1
	ENGINE				

6/54





FIG. 5B



			536	i i					
SERVICE	PORT	P1		P1		Ъ4		P1	
SOURCE DESTINATION SERVICE	₾	W1		W1		101		U1	
SOURCE	<u>a</u>	U1		U1		W1		W1	
T 0		PACKETING	ENGINE	S1		PACKETING W1	ENGINE	01	
STEP FROM		U1		PACKETING	ENGINE	S1		PACKETING	ENGINE
STEP		-		2		က		4	

FIG. 5F

	VE BACKET MIBOR	TABLE MAINTAIN	NED BY PAC	AINTAINED BY PACKETING ENGINE	INE.		
בו בו	RECEIVE PACKET INBOUND TO PACKETING ENGINE	ND 10 PACKETING	G ENGINE	SENDII	JUTBOUND FR	SEND IT OUTBOUND FROM PACKETING ENGINE	G ENGINE
	SOURCE	DESTINATION	SERVICE	SEND VIA	DEST.	SEND PACKET TO	SKET TO
N O	ADDRESS	IP ADDRESS	PORT	INT.	SYSTEM		
	MAC				TYPE	MAC	dl
		W1	P1	_	ALIAS	S1 _M	W1
	S1 _M W1		P1	0	ROUTER		DEFAULT ROUTE
				537	2	538	

FIG. 5G





FIG. 5H




STEP	FROM	10	SOURCE IP	DESTINATION IP	PORT
			PORTPT		
\	U1 (CLIENT)	PACKETING ENGINE		1	P1
2	PACKETING	S1 (SERVER)	U1	S1 (IF NAT IS	P1
	ENGINE			REQUIRED); W1 (IF S1	
				SUPPORTS LOOPBACK OR ALIAS)	
က	S1	PACKETING	S1 (IF NAT IS	01	P 1
		ENGINE	REQUIRED); W1 (IF S1		
			OR ALIAS)		
4	PACKETING	01	W1	01	P 1
	ENGINE				
			PORT P2		
14	U1 (CLIENT)	PACKETING	101	W1	P2
		ENGINE			
2A	PACKETING	S2 (SERVER)	10	S2 (IF NAT IS	P2
	ENGINE			REQUIRED); W1 (IF S2	
				SUPPORTS LOOPBACK	•
3A	S1	PACKETING	S2 (IF NAT IS	U1	D2
			REQUIRED); W1 (IF S1		I
			SUPPORTS LOOPBACK		
			OR ALIAS)		
4 4	PACKETING ENGINE	N1	W1	U1	P2
			FIG. 6A	631	

12/54

FIG. 6A

		TABLE	MAINTAINED	E MAINTAINED BY PACKETING ENGINE	NGINE		
RECE	RECEIVE PACKET INBOUND TO PACKETING ENGINE	INBOUND TO P ENGINE	ACKETING	SEND IT OU	SEND IT OUTBOUND FROM PACKETING ENGINE	KETING E	NGINE
O K	SE SE	DEST. IP ADDRESS	SERVICE PORT	SEND VIA INT.	DEST. SYSTEM TYPE	SEND P.	SEND PACKET TO
Ž	MAC					MAC	<u>a</u>
0		W1	Pd		LOOPBACK	S1 _M	W1
		•			ALIAS	S1 _M	W1
					NAT		S1
<u>-</u>			Ď.	0	ROUTER		DEFAULT
	S1 _M S1			I ₀ (AFTER			ROUTE
				REVERSE NAT			
				SOURCE IP TO			
				(1 //			
<u>_</u>		X	P2	7-	LOOPBACK	$S2_{M}$	W1
					ALIAS	$S2_{M}$	W1
					NAT		S2
			P2	0	ROUTER		DEFAULT
	SZ _M S2					100 mm m	ROUTE
	-			SOURCE ID TO			
			_	W1)			
				FIG. 6B	632	7	




the drive with sum and the control of the control o

PORT	P1	P1	Ъ1	P1	P2	P2	P2	P2		P2	P2	P1	P1	P4	P 1
DESTINATION IP	W1	W1	W1	W1	W1	W1	APP1 (IF NAT REQUIRED); W1 (IF LOOPBACK OR ALIAS SUPPORTED BY APP1)	<u></u>		U	U	U 1	U1	D1	U1
SOURCE IP	7	101	11	101	10	10	10	APP1 (IF NAT REQUIRED); W1 (IF	ALIAS SUPPORTED BY APP1)	W1	W1	W1	M1	W1	W1
10	PACKETING ENGINE	FW (INTERFACE FW0)	PACKETING ENGINE	VPN	PACKETING ENGINE	IDS	APP1	PACKETING ENGINE		IDS	VPV	PACKETING ENGINE	FW (INTERFACE FW1)	PACKETING ENGINE	U1
FROM	U1 (CLIENT)	PACKETING ENGINE	FW (INTERFACE FW1)	PACKETING ENGINE	VPN	PACKETING ENGINE	PACKETING ENGINE	APP1		PACKETING ENGINE	PACKETING ENGINE		1	ACE	PACKETING ENGINE
STEP	~	2	က	4	2	6A	6B	_		8A	8B	<u>ග</u>	10		12

FIG. 7A

			TABLE MAIN	MAINTAINED BY PACKETING ENGINE	ACKETING	ENGINE		
RECE	IVE PACK	ET INBOUN ENGINE	RECEIVE PACKET INBOUND TO PACKETING ENGINE	CKETING	SEND	SEND IT OUTBOUND FROM PACKETING ENGINE	M PACKETING	ENGINE
RCX ON INT.	SOURCE Address	CE ESS	DEST. IP Address	SERVICE PORT	SEND VIA IINT.	DEST. SYSTEM TYPE	SEND PACKET TO	CKET TO
•	MAC	<u>d</u>					MAC	Ы
0			W1	P1	1	TRANSPARENT	FW0™	W1
2	FW1 _M		W1	Þ	12	TRANSPARENT	VPN	W1
2	VPN_M		W1	P2	-	TRANSPARENT	IDS _M	W1
-					3	LOOPBACK	APP1 _M	W1
						ALIAS	APP1 _M	W1
					•	NAT		APP1
1	IDSM			P2	13	LOOPBACK	APP1 _M	W1
						ALIAS	APP1 _M	W1
						NAT		APP1
]	APP1 _M	APP1		P2	1	TRANSPARENT	IDS™	
		S ×			- 12	TRANSPARENT	VPN™	
2	VPN™	W1		P1	12	TRANSPARENT	FW1™	
	FW0 _M	W1		Ď	0	ROUTER		DEFAULT
								HOO IE

FIG. 7B




STEP	FROM	10	SOURCE IP	DESTINATION IP	SERVICE
		PACKETING ENGINE	01	W1	P4
	PACKETING ENGINE	FW (INTERFACE FW0)	U1	W1	P1
	CE	PACKETING ENGINE	01	W1	P 1
4A	PACKETING ENGINE	IDS	10	W1	P1
4B	PACKETING ENGINE	APP1	<u>U</u>	APP1 (IF NAT REQUIRED); W1 (IF LOOPBACK OR ALIAS SUPPORTED BY APP1)	TP1
	APP1	PACKETING ENGINE	APP1 (IF NAT REQUIRED); W1 (IF LOOPBACK OR ALIAS SUPPORTED BY APP1)	, ,	TP.
	PACKETING ENGINE	IDS	W1	01	P1
6B	PACKETING ENGINE	FW (INTERFACE FW1)	W1	0.1	Ъ1
	FW (INTERFACE FW0)	PACKETING ENGINE	W1	U1	P1
	PACKETING ENGINE	01	W1	U1	P1

FIG. 8B

NOINE		O PORT	<u> </u>	P1	P1	TP1	TP1	TP1	TP1	ТР1	TP1	Д.	P1	T D1	
CKETINIC		SEND PACKET TO	<u>d</u>	W1	W1	, W1	, W1	APP1	- W1	_ W1	APP1			DEFAUL	ROUTE
N EDOM BY			MAC	FW0 _M		APP1 _M	APP1 _M		APP1 _M	APP1 _M			FW1 _M		
MAINTAINED BY PACKETING ENGINE		DEST. SYSTEM] : :	TRANSPARENT	TRANSPARENT	LOOPBACK	ALIAS	NAT	LOOPBACK	ALIAS	NAT	TRANSPARENT	TRANSPARENT	ROUTER	
Y PACKET		SEND	N.	-	-	- 13	-		13		· i	_	12		•
NTAINED B		SERVICE		P1	Ъ				P			TP1		ğ	•
TABLE MAINTAINEL RECEIVE PACKET INBOLIND TO PACKETING	ENGINE	DEST. IP ADDRESS		W1	W1										
ACKET IN		SOURCE Address	<u>d</u>										S S S S		
CFIVE P		SO	MAC		FWM				^{M}SM			APP1 _M		FW	2
X	!	% S S S N	N.	0	12							ا ₃		-	-

1G. 8C

833



£23
1
£ 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Anne
The state of the s
A
e a series
\$=#
×
Handi Street
Hearty Heart.
Handi Street
that Apal arth State
that Apal arth State
the thirt is


STEP	FROM	10	SOURCE IP	DESTINATION IP	PORT
_	U1 (CLIENT)	PACKETING ENGINE	U1	W1	P1
2	PACKETING ENGINE	FIREWALL F1 (INT. FW0)	U1	W1	P1
3	FIREWALL F1 (INT. FW1)	PACKETING ENGINE	<u>U1</u>	W1	P 4
4A	PACKETING ENGINE	IDS	01	W1	P1
4B	PACKETING ENGINE	APP1	U1	APP1 (IF NAT); W1	Ъ
				(IF LOOPBACK OR ALIAS)	
2	APP1	PACKETING ENGINE	APP1 (IF NAT); W1	N1	P1
			(IF LOOPBACK OK ALIAS)		
6A	PACKETING ENGINE	IDS	W1	U1	Ъ1
6B	PACKETING ENGINE	FIREWALL F1 (INT. FW1)	W1	101	Ъ1
7	FIREWALL F1 (INT. FW0)	PACKETING ENGINE	W1	U1	Р1
ω.	PACKETING ENGINE	U1	W1	10	P
တ	U1 (CLIENT)	PACKETING ENGINE	10	W1	D1
10	PACKETING ENGINE	FIREWALL F1 (INT. FW0)	U1	W1	D1
_	FIREWALL F1 (INT. FW1)	PACKETING ENGINE	01	W1	D1
12A	PACKETING ENGINE	IDS	U 1	Ŵ1	D1
12B	PACKETING ENGINE	APP1	01	APP1 (IF NAT); W1	D 1
				(IF LOOPBACK OR ALIAS)	
13	APP1	PACKETING ENGINE	APP1 (IF NAT); W1	01	D1
			(IF LOOPBACK OR ALIAS)		
14A		IDS	W1	U1	D1
14B	PACKETING ENGINE	FIREWALL F1 (INT. FW1)	W1	01	D1
15	FIREWALL F1 (INT. FW0)	PACKETING ENGINE	W1	U1	5
16	PACKETING ENGINE	01	W1	7	D1

FIG. 9A

RCX ON INT.	SOURCE ADDRESS MAC	T INBOUN RCE RESS	TABLES MAIN ND TO PACKE DEST. IP ADDRESS	RECEIVE PACKET INBOUND TO PACKETING ENGINE RECEIVE PACKET INBOUND TO PACKETING ENGINE RECEIVE PACKET INBOUND TO PACKETING ENGINE RECEIVE PACKETING ENGINE SEND TO DEST. ON ADDRESS ADDRESS PORT VIA INT. MAC IP	SEND SEND SEND VIA VIA INT.	SEND IT OUTBOUND FROM PACKETING ENGINE SEND DEST. SYSTEM SEND PACKET TO VIA TYPE MAC IP	SEND PACKETII	ACKETING ENGINE SEND PACKET TO MAC IP
0			W1	P1 OR PORT IN RANGE OF 1025→1125		TRANSPARENT	FW0 _M	W1
2	FW1 _M		W1	P1 OR PORT IN RANGE OF 1025→1125	- E	TRANSPARENT LOOPBACK ALIAS NAT	IDS _M APP1 _M APP1 _M	W1 W1 APP1
	IDS ™			P1 OR PORT IN RANGE OF 1025→1125	က	LOOPBACK ALIAS NAT	APP1 APP1 _M	W1 W1 APP1
-	APP1 _M	APP1 OR W1		P1 OR PORT IN RANGE OF 1025→1125	2 2	TRANSPARENT	IDS _M FW1 _M	
	FW2™	M1		P1 OR PORT IN RANGE OF 1025→1125	0	ROUTER		DEFAULT ROUTE


i.G. 9B


6





	T		Т	<u> </u>	T				I				т	<u> </u>	Т	Γ		1	т			<u> </u>	Т	1	_	1	24/5	54
PORT	P1	Ρ1	P1	P1	P1				P1				P1	P1	P1	Ъ1	D1	D1	D1	10	D1	D 1	D1	D1	D1	D1		
DESTINATION IP	W1	W1	W1	W1	APP1 (IF NAT	REQUIRED); W1 (IF	ALIAS SUPPORTED	BY APP1)	01				U1	01	01	01	APP1	APP1	APP1	APP1	APP1	U1	01	01	01	01	934	
SOURCE IP	U1	<u>U1</u>	U1	01	01				APP1 (IF NAT	REQUIRED); W1 (IF	ALIAS SUPPORTED	BY APP1)	W1	W1	W1	W1	U1	U1	01	10	U1	APP1	APP1	APP1	APP1	APP1	0	
T0	PACKETING ENGINE	F1 (INT. FW0)	PACKETING ENGINE	IDS	APP1				PACKETING ENGINE				SQI	F1 (INT. FW1)	PACKETING ENGINE	10	PACKETING ENGINE	F2 (INT. FW0)	PACKETING ENGINE	IDS	APP1	PACKETING ENGINE	IDS	F2 (INT. FW1)	PACKETING ENGINE	U1		FIG. 9D
FROM	U1 (CLIENT)	PACKETING ENGINE	F1 (INT. FW1)	PACKETING ENGINE	PACKETING ENGINE				APP1				PACKETING ENGINE	PACKETING ENGINE	F1 (INT. FW0)	PACKETING ENGINE	U1 (CLIENT)	PACKETING ENGINE	F2 (INT. FW1)	PACKETING ENGINE	PACKETING ENGINE	APP1	PACKETING ENGINE	PACKETING ENGINE	F2 (INT. FW0)	PACKETING ENGINE		
STEP	_	2	3	4 A	4B				ഹ					6B			6	10			m m			m		16		

	-	,		,																						25	/5	4
S ENGINE	CKET TO	<u>a</u>	W1	W1	W1	W1	APP1	W1	W1	APP1				DEFAULT	ROUTE	APP1	APP1	APP1		APP1				DEFAULT	ROUTE			
OM PACKETING	SEND PACKET TO	MAC	F1(FW0) _M	IDS™	APP1 _M	APP1 _M		APP1 _M	APP1 _M		IDS _M	F1(FW1) _M				F2(FW0) _™	IDS _M	APP1 _M		APP1 _M		IDS_M	F2(FW1) _M	B				
(ETING ENGINE SEND IT OUTBOUND FROM PACKETING ENGINE	DEST. SYSTEM TYPE		TRANSPARENT	TRANSPARENT	LOOPBACK	ALIAS	NAT	LOOPBACK	ALIAS	NAT	TRANSPARENT	TRANSPARENT		ROUTER		TRANSPARENT	TRANSPARENT	SERVER IP	ADDRESS	SERVER IP	ADDRESS	TRANSPARENT	TRANSPARENT	ROUTER		S	935	
PACKETING SEND	SEND VIA INT.		1	1	3			3		.		2		01		Ч	1	3		<u>8</u>		_+	2	0				FIG. 9E
NTAINED BY PACKETING ENGINE ING ENGINE SEND IT OUTBO	SERVICE PORT		P	P1				P1			P1			P1		PORT>1024	PORT>1024			PORT>1024		PORT>1024		PORT>1024				Ĭ
TABLES MAI O TO PACKET	DEST. IP ADDRESS		W1	W1					A STATE OF THE STA				100			APP1	APP1							200 pt				
TABLES MA RECEIVE PACKET INBOUND TO PACKET	SOURCE ADDRESS	MAC IP		F1(FW1) _M				IDS™			APP1 _M APP1	80 :		F1(FW0) _M W1			F2(FW1) _M			IDS _M		APP1 _M APP1		F2(FW0) _M APP1				
RECEIVE	ON NO	.TNI	0	2	7					-	-3					0		,				<u>8</u>		<u> </u>				












FIG. 13




FIG. 14

SERVICE IP ADDRESS W1

=		F5	A4		
INTRUSION	DETECTION	FIREWALL	APPLICATION	SERVER	
STEP W1-1		STEP W1-2/3	STEP W1-4		

FIG. 14A

SERVICE IP ADDRESS W5

F5	A4
FIREWALL	APPLICATION SERVER
STEP W5-1/2	STEP W5-3

FIG. 14B

L1432

SERVICE IP ADDRESS W1D

STEP W1D-1 DATABASE D1 SERVER

FIG. 14C

STEP W5D-1 DATABASE D1
SERVER
FIG. 14D






FIG. 15







-IG. 15B

<u> </u>	7				
	COINE	SEND PACKET TO	d		W1
	M PACKETING EN	SEND PA	MAC	FIREWALL F1M	FIREWALL F2 _M
	SEND IT OUTBOUND FROM PACKETING ENGINE	DEST. SYSTEM	TYPE	TRANSPARENT	TRANSPARENT
	SEN	SEND FROM	INTERFACE		1

FIG. 15C








FIG. 16A





FIG. 16B







FIG. 17A






FIG. 17E






FIG. 17H











FIG. 18




2090

FIG. 20










FIG. 24